



Wildcat Trail/Sport doors Panel Installation guide PO-WT-5017)

Parts			
Réf.	# NUMBER	Description	QTY
1	PO-WT-17D	Right plastic panel	1
2	PO-WT-17G	Left plastic panel	1
3	CFT-TS17R-10	Mounting Collar	4
4	M6U-12669	U-nut	4
5	HEX-12160	Hexagon head bolt	4
6	MCPO-42	Edge Molding 42"	2

Needed tools: box torx t20, Drill/Driver 5 / 16".

Step 1: Remove the 2, T30, bolts refer to the arrows in picture. Insert the tube clamps, one in front and the other one in back.



Step 2 : Install U clamps (front and rear) by adjusting the center hole of the panel on original door center hole. Then remove panel and place the U-nuts so that the tube clamps are held in the correct position, aligning the holes



Step 3 : Fix center screw and the 2 hex head bolts (8mm) on panel. Lay the contour molding

