



Arctic Cat WildCat 700 Trail/Sport Blow Hole Install Instructions



1. Remove Driver's seat. Locate rubber duct located on top of the clutch cover. Loosen hose clamp and remove rubber duct. You will re-use the hose clamp.



2. Install Blow Hole as shown onto the clutch cover with straight silicone towards the clutch cover. Align MTNTK Graphics as shown. This will insure proper routing. Use the stock clamp and fasten the Blow Hole to the Clutch Cover.



3. Carefully Route the Blow Hole wiring harness down the factory harness and under the driver seat towards the front of the machine. Secure wires so they do not rub.



4. Locate the stock accessory plug and insert the Blow Hole harness plug: Red to Orange, Black to White. This allows you to still use the factory accessory plug. Reinstall Driver's seat.

MTNTKperformance.com